


KitchenAid®

COOKTOP PARTS

For Models: KESS908SPB01, KESS908SPW01, KESS908SPS01
(Black) (White) (Stainless)

30" SLIDE-IN
ELECTRIC OVEN
SELF CLEAN



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP PARTS

For Models: KESS908SPB01, KESS908SPW01, KESS908SPS01

(Black)

(White)

(Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	4		Cooktop	13	9761423	Frame, Cooktop
	W10118260	Installation Instructions		W10110273	Black/Stainless			Front
	W10118258	Use & Care Guide		W10110272	White	14	3196537	Screw
	W10112131	Tech Sheet	5	9757824	Rail, Element Side	15	341196	Thermostat
	9763467	Easy Set Guide	6	9761638	Box, Tap Touch	16	3196160	Screw
	9757680	Anti-Tip Instructions	7	W10076030	Gasket (2)	17	9761663	Seal, Heat
		Safe Cooking Tips	8	4449745	Screw	18	9757815	Support, Module
	3191638	English	9	9759944	Thermostat	19	9759094	Spring, Locator
	9759133	French	10	9756821	Support, Wiring	20	9761768	Frame, Cooktop
2	8285348	Module, Appliance Manager	11	9757825	Rail, Element Center (1)			Rear
3	9761422	Frame, Cooktop Side	12		Element, Surface	21	9763517	Rail, Element (2)
				8285232	LR/1000W	22	246119	Screw
				4453907	RF/1500W	23	9761723	Cover, Cooktop
				4453910	RR/1900W			Rear
				4453908	LF/2300W	24	9757063	Module, Tap Touch

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


OVEN PARTS

For Models: KESS908SPB01, KESS908SPW01, KESS908SPS01

(Black)

(White)

(Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: KESS908SPB01, KESS908SPW01, KESS908SPS01

(Black)

(White)

(Stainless)

Illus. No.	Part No.	DESCRIPTION
1		Trim, Side Right
	W10109540	Black
	W10109570	White
	W10140548	Stainless
		Left
	W10109490	Black
	W10109520	White
	W10140547	Stainless
2	3400832	Screw
3		Hinge Receiver
	4455606	Right
	4455605	Left
4	W10105790	Bumper, Door (2)
5	3196537	Screw
6	3196160	Screw
7	8303099	Top Chassis
8	4449809	Screw
9	4452158	Tube, Vent
10	W10067870	Lens, Light (2)
11	W10009930	Oven Light, Assembly (2)
12	4452166	Bulb, Light (2)
13	4449154	Screw
14	W10130368	Frame, Front
15	W10074200	Gasket, Door
16	9757829	Bracket, Transformer
17	4452152	Bracket, Mounting
18	9757685	Guide, Side Panel
19	4451478	Support, Insulation

Illus. No.	Part No.	DESCRIPTION
20		Body, Side
	9760723PB	Black/Stainless
	9760723PW	White
21	9757461	Bracket, Side Panel
22	9760888	Latch, Motorized
23	9759242	Thermostat
24	9757811	Brace, Side Panel
25	4455641	Side, Chassis
26	9759761	Back, Chassis
27		Liner, Oven (Not Serviceable)
28	9759890	Clip, Side Panel
29	W10131825	Sensor
31	3196176	Screw
33	9759713	Base, Chassis
34	4448933	Retainer, Gasket
35	4448444	Grommet, Mounting Rail
36		Vent, Bottom Upper
	9756481BL	Black
	9756481WH	White
	W10140533	Stainless
37		Vent, Bottom Lower
	W10104890	Black
	W10104910	White
	W10140546	Stainless
38	4449743	Screw
41	W10111628	Transformer, Control

Illus. No.	Part No.	DESCRIPTION
42	4449868	Block, Terminal
43	3400080	Screw
44	9757404	Box, Terminal
45	9757405	Cover, Terminal Box
46	9759721	Insulator, Terminal Box
47	9761958	Block, Terminal
48	9761801	Appliance, Manager
49	W10083460	Slide, GOC
50	9756454	Bracket, Appliance Manager
51	9759884	Insulation
52	9759722	Insulation, Body Side
53	9760481	Washer
54	9758583	Cover, Back
55	9759885	Pad, Insulation(2)
56	9759945	Standoff, Rear

FOLLOWING PARTS NOT ILLUSTRATED


INSULATION

9756817	Insulation, Wrap
9756470	Insulation, Back

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: KESS908SPB01, KESS908SPW01, KESS908SPS01
(Black) (White) (Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: KESS908SPB01, KESS908SPW01, KESS908SPS01

(Black)

(White)

(Stainless)

Illus. No.	Part No.	DESCRIPTION
1	9759413	Panel, Door
2	9757706	Glass, Inner
3	4451722	Insulation, Door
4	4457132	Retainer, Glass
5		Hinge, Oven Door
	9760579	Right
	9760580	Left
6	9759225	Glass, Inner
7	4457114	Shield, Heat
		Bottom
8	9759229	Bracket, Glass
		Side
9	4457103	Shield, Heat Top
10	9759225	Glass, Inner Door
11	9759230	Bracket, Central
12		Bracket, Handle
	9763497	Right
	9763496	Left
13		Badge
	8304603BL	Black
	8304603WH	White
	8304603SS	Stainless
14		Assembly, Door
		Kit
	W10131888	Black
	W10131889	White
	W10155557	Stainless
15		Handle, Door
	8303774BL	Black
	8303774WH	White
	8303774SS	Stainless
16	3196184	Screw
19	4448520	Bumper, Door

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


DRAWER PARTS

For Models: KESS908SPB01, KESS908SPW01, KESS908SPS01

(Black)

(White)

(Stainless)



Illus. No.	Part No.	DESCRIPTION
1		Support, Drawer Rail
	9757687	Right
	9757686	Left
2	9763501BL	Support, Front & Rear
3		Brace, Drawer
	4453720	Right
	4453721	Left
5		Side, Base
	9759953	Right
	9759954	Left


Illus. No.	Part No.	DESCRIPTION
6	W10058460	Foot
7	8274149	Thermistor
8	3196037	Foot Assembly
10	W10144430	Drawer
11		Drawer Slide
	W10019810	Right
	W10019800	Left
12	W10140544	Panel, Drawer Front, Drawer
13		
	9761747BL	Black
	9761747WH	White
	W10140545	Stainless

Illus. No.	Part No.	DESCRIPTION
14		Handle, Drawer
	9761573BL	Black
	9761573WH	White
	9761573SS	Stainless
15	3196537	Screw
16	W10045140	Cover, Terminal
17	9758676	Support, Element
18	9760775	Element, Warming Drawer
19	9763518	Enclosure, Warming Drawer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: KESS908SPB01, KESS908SPW01, KESS908SPS01
(Black) (White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	W10117033	Control Panel Black
	W10117034	Control Panel White
	W10156272	Control Panel Stainless
2	W10110246	Gasket, Console
3	9761799	Control, Electric

Illus. No.	Part No.	DESCRIPTION
4	W10105370	Shield, Console Vent
5	W10117524	Bracket, Console
6	3196160	Screw
7	9761745	Bracket, Thermostat (2)

Illus. No.	Part No.	DESCRIPTION
8	W10116195	Gasket, Vent Shield
9	3196537	Screw
10	9780271	Screw
11	9761566	Membrane, Switch

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


INTERNAL OVEN PARTS

For Models: KESS908SPB01, KESS908SPW01, KESS908SPS01

(Black)

(White)

(Stainless)



Illus. No.	Part No.	DESCRIPTION
1	9760774	Element, Broil
2	4449154	Screw
6	4448717	Rack, Oven
7	9760768	Element, Bake
8	9755542	Probe, Meat


Illus. No.	Part No.	DESCRIPTION
9	9760769	Element, Convection
10	9756690	Cover, Fan
11	4455037	Tray, Hidden Bake
12	4450039	Cover, Bake Tray
13	4451583	Motor, Convection

Illus. No.	Part No.	DESCRIPTION
14	4452227	Nut
15	4452226	Blade, Fan
16	9755543	Jack, Meat Probe
17	9755547	Lock Washer
18	9755546	Hex Nut

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: KESS908SPB01, KESS908SPW01, KESS908SPS01
(Black) (White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust
2	4455178	Elbow, Vent Top
3	9759320	Blower
4	4451758	Block, Foam
5	4455177	Elbow, Vent Bottom
6	9759938	Bracket, Terminal Box
7	4449809	Screw (2)
10	4449040	Screw
11	4455352	Bracket, Blower

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: KESS908SPB01, KESS908SPW01, KESS908SPS01
(Black) (White) (Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
OPTIONAL PARTS NOT INCLUDED			SPLICING WIRES--25FT. LENGTH			WIRING HARNESS PARTS		
PAINT, TOUCH-UP (1/2oz.)			242828	Wire (12 Ga. 150 c Black)		W10118728	Harness, Main	
72017	White		242820	Wire (14 Ga. 150 c Black)		8285319	Cable, Board Connection	
261869	Cord Brown		242821	Wire (14 Ga. 150 c Blue)		W10157935	Harness, Switch	
72032	Black		242822	Wire (14 Ga. 150 c Brown)		9762921	Harness, Communication	
PAINT, SPRAY			242830	Wire (14 Ga. 200 c Brown)		4452222	Spacer, Harness	
350930	White		242823	Wire (14 Ga. 150 c Green)		9763481	Harness, Ground Strap	
261900	Citrine White		242824	Wire (14 Ga. 150 c Orange)		W10115168	Cooktop, Tap Touch Switch	
830864	Black		242825	Wire (14 Ga. 150 c Red)		9759715	Conduit	
ADHESIVE			242831	Wire (14 Ga. 200 c Red)		313660	Clip, Ground Wire	
591014	Adhesive Loctite (1/3 oz.)		242827	Wire (14 Ga. 150 c Yellow)		4448664	Clamp	
482338	Sealer, Silastic (3 oz.)					9756675	Grommet, Flexible	
						9757778	Bushing, Snap, Split 1"	
						W10076020	Gasket	
						4449809	Screw	
						112432	Nut	
						4450800	Screw, Ground	
						3400015	Screw, Ground	
						Miscellaneous		
						9782676	Anti-Tip Assembly Filler, Counter Top	
						W10113902A	Black	
						W10113903A	White	
						W10113901A	Stainless	

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST